

USE & CARE INSTRUCTIONS

EASY TO FILL, EASY TO CLEAN

Wide top allows you to fill and clean with ease.

GENTLY ROTATE THE ROOF TO THE LEFT TO OPEN



Filling the Feeder


Step 1: Remove the locking roof by turning a quarter turn to the left and lifting.

Step 2: Pour seed into the wide top.

Step 3: Replace the metal roof and twist right to lock. Your feeder is now ready to hand. The locking metal roof keeps squirrels out of your feeder.

Cleaning the Feeder

Remove the locking metal roof by turning it a quarter turn to the left and lifting. Push the bronze plastic bar down to release it from its tabs, and pull the entire piece out of the feeder. Hand wash with warm water and a mild antibacterial soap. Drain holes in the base will allow water to flow through and clean the bottom. If you need to remove the base to clean the bottom of the feeder, use a small screwdriver to unscrew the screws on either side of the base. Base should separate easily from the plastic tube. Rinse the feeder thoroughly and let dry completely before refilling with seed.




Squirrel-Proof Ports

Two integrated metal perches are spring loaded to close both ports from the weight of a squirrel.

Place feeders at least 12-15 feet from any surface the squirrel can jump from.

Deter squirrels from your feeder by adding a squirrel baffle.



TENSION ADJUSTMENT PIN

Choose Your Birds®

Use the tension adjustment pin below the perch to Choose Your Birds®. Use your feeder with the pin in the down position for smaller birds. Larger birds can perch with the pin in the up position.